

## **SIZED FOR SPACING**

SIZED FOR SPACING is a notation in APA Rated Sheathing, APA Rated Sturd-I-Floor® and APA Rated Siding trademarks indicating panels may be trimmed during manufacture to length and width tolerances of +0, -1/8 inch. This trimming is designed to encourage proper panel spacing.

The size tolerance given in PS 1-95 is +0, -1/16 inch, of the specified length and width. The size tolerance given in PS 2-04 and in APA PRP-108 is +0, -1/8 inch of the specified length and width.

The SIZED FOR SPACING notation in the APA trademark stamp is a notification to the customer that the panel may, if the manufacturer chooses, be 1/8-inch smaller than the specified length and width, regardless of the size tolerance specified in the manufacturing standard. The size tolerance of a panel sold as 48 x 96 inches, SIZED FOR SPACING may, therefore, be 1/8 inch less than the specified length and width (e.g., 47-7/8 x 95-7/8 inches).

Since the size tolerance given in PS 2-04 and PRP-108 allows up to 1/8 inch less than the specified length and width, a 47-7/8- x 95-7/8-inch panel may or may not be stamped SIZED FOR SPACING.

The SIZED FOR SPACING notation can be used on any APA Rated Sheathing, APA Rated Sturd-I-Floor or APA Rated Siding panels cut to less than full length and width. Panels that are full length and width, however, and bear a SIZED FOR SPACING mark, would not likely be considered as undergrade. Moisture may have caused them to increase to the maximum size tolerance.

Technical Services Division

**Disclaimer**

*The information contained herein is based on APA – The Engineered Wood Association’s continuing programs of laboratory testing, product research, and comprehensive field experience. Neither APA nor its members make any warranty, expressed or implied, or assume any legal liability or responsibility for the use, application of, and/or reference to opinions, findings, conclusions, or recommendations included in this publication. Consult your local jurisdiction or design professional to assure compliance with code, construction, and performance requirements. Because APA has no control over quality of workmanship or the conditions under which engineered wood products are used, it cannot accept responsibility of product performance or designs as actually constructed.*